



## GLITSA CLEAN

### WOOD FLOOR CLEANER

*Glitsa Clean* is an excellent cleaner for wood floors, as well as other interior wood surfaces. *Glitsa Clean* contains no surface dulling oils that collect dust and dirt, nor does it contain any waxy polishes to build up on the surface of your floor finish. *Glitsa Clean* is available in concentrate form in quarts and gallons and in the new Ready-to-Use 32oz. spray bottle.

#### *Specifications*

- Water based formula
- Neutral pH
- Fresh scent
- Leaves no residue
- Biodegradable
- Contains no phosphates
- No rinsing required
- Recyclable container

#### *Directions*

Dust-mop with the Glitsa Mop and Dust Pad before cleaning wood floors to remove any loose dirt. *For Concentrate:* Mix one cup *Glitsa Clean* to each gallon of warm water. *For Ready-to-Use:* Simply spray onto floor or cloth. Damp mop or sponge surface thoroughly. Do not soak the floor. Allow to air dry. No rinsing required. *Glitsa Clean* concentrate may be used at full strength on stubborn spots. Wipe clean using a damp Cleaning Pad on the Glitsa Mop. **Note:** Do not use cleaner in the first two weeks after the final finish coat is applied.

#### *General maintenance*

Use the untreated Glitsa Mop with Dust Pad on your floor regularly. This will keep the sand and grit off the floor that may cause premature wear. Place rugs, which are cleaned on a regular basis, in entryways and in front of sink areas, to minimize the amount of dirt and water that comes in contact with your wood floor. Wipe up food and other spills immediately with a dampened (not soaking wet) Glitsa Mop with Cleaning Pad or a paper towel. Regular cleaning should be done with *Glitsa Clean* and the *Glitsa Mop*. See Glitsa's "Wood Floor Maintenance Brochure" for additional information.