

PALL-X RETARDER

Dry time extender for all PALLMANN waterborne wood floor finishes

Description

PALLMANN® Pall-X Retarder is a dry time extender for all PALLMANN waterborne wood floor finishes. It is designed to provide optimum flow and leveling to PALLMANN finishes in challenging warm and dry climatic conditions.

Note: Optimum application conditions for finishes are 65-80°F with 40-60% relative humidity. The use of Pall-X Retarder is recommended when temperatures exceed 80°F and relative humidity drops below 30%.

Technical Data

Packaging:	1 quart plastic bottle
Color:	Clear
Stability:	Minimum 12 months
Mixing Ratio:	Maximum 5% retarder to finish by volume
Storage:	Store between 50-70°F (10-20°C). Keep from freezing.



FLOW TIM

Directions for Use

- Bring Pall-X Retarder to room temperature.
- Shake each container of finish vigorously for approximately 1 minute making sure all ingredients are well mixed. Failing to mix any finish product may result in streaking when finish is dry. DO NOT ADD WATER TO FINISH.
- 3. Add a maximum of 5% (6.5 ozs.) Pall-X Retarder to 1 gallon (128 ozs.) of finish and shake vigorously for 1 minute. The Retarder must be thoroughly mixed with the finish.
- 4. Apply finish with a T-bar applicator, roller, cut-in pad or brush.

Important Notes:

- Finish mixed with Retarder should be used within 5 days.
- When using Pall-X 98, Retarder must be mixed with Component A (finish) before Component B (hardener) is added.

Clean Up

Tools and applicators should be cleaned with water.

Storage

Minimum 12 months in original packaging when stored under normal conditions (50-70°F/10-20°C). Tightly reseal opened containers. Keep from freezing.

Disposal

Dispose of empty containers according to local, state and federal regulations.

Precautions

CAUTION: Keep out of reach of children. Keep container closed during storage. Avoid contact with eyes and skin. Avoid breathing vapors. Use only in well-ventilated areas. Use of protective gloves (rubber) and safety glasses is recommended. Nonflammable.

FIRST AID: In case of skin contact, wash thoroughly with soap and water. For eye contact, flush immediately with large amounts of water for at least 15 minutes and obtain medical treatment. If swallowed, obtain medical treatment immediately.

IFLOOR TEMS

UFLOOR Systems Inc. Toll free 866-505-4810 | 720-374-4810 14509 E. 33rd Place, Unit G, Aurora CO 80011 ufloorsystems.com



01/08/13